

油 圧		トルク値
Bar	MPa	N・m
103	10	9,294
110	11	10,274
124	12	11,260
131	13	12,254
138	14	13,466
152	15	14,440
159	16	15,414
165	17	16,384
179	18	17,368
193	19	18,344
200	20	19,312
207	21	20,292
221	22	21,268
234	23	22,238
241	24	23,206
248	25	24,188
262	26	25,160
269	27	26,134
276	28	27,100
290	29	28,072
303	30	29,048
310	31	30,026
317	32	30,994
331	33	31,968
345	34	32,936
352	35	33,900
359	36	34,874
372	37	35,844
379	38	36,812
386	39	37,786
400	40	38,738

油 圧		トルク値
Bar	MPa	N・m
414	41	39,706
421	42	40,660
427	43	41,628
441	44	42,590
455	45	43,554
462	46	44,502
469	47	45,470
483	48	46,452
490	49	47,496
496	50	48,516
510	51	49,556
524	52	50,498
531	53	51,476
538	54	52,454
552	55	53,432
558	56	54,410
565	57	55,388
579	58	56,366
593	59	57,344
600	60	58,322
607	61	59,301
621	62	60,279
634	63	61,257
641	64	62,235
648	65	63,213
662	66	64,191
669	67	65,169
676	68	66,147
689	69	67,125
703	70	68,103

事前の承認なしに、この換算表の一部分のみを複製してはならない。

株式会社 タイタンジャパン

TEL (078)919-5219

〒651-2122 兵庫県神戸市西区玉津町高津橋280-16 FAX (078)919-5229 E-mail : info@titanti-jp.com

URL : [www.titanti-jp.com](http://www.titanti-jp.com)